



Covalence®

Heat Shrinkable Technology

SEALFORLIFE

ELCOMETER 154 WET FILM THICKNESS



DESCRIPTION

Elcometer 154 Wet Film Combs are designed to be used only once and kept as a record of wet film thickness measurement for ISO or customer requirements.

TECHNICAL SPECIFICATION

Both Metric and imperial values are on the same comb, 50 to 800µm on one side, 2 to 32 mils on the reverse

Instructions for use: Place a comb perpendicular to and touching the substrate. Hold the comb in position and wait a few seconds until the teeth are wet. Remove the comb from the film. The wet film thickness lies between the biggest value 'coated' or 'wet' tooth and the smallest value 'uncoated' or 'dry' tooth.

ORDERING INFORMATION

Description:	EQ-ELCOMETER-WET FILM-GAUGE154
Model no.:	Elcometer 154-1
Unit of Measure:	PC
Pcs per package:	1 pc
Minimum order quantity:	1 pc



www.sealforlife.com

DISCLAIMER: Berry Plastics warrants that the product(s) represented within conform(s) to its/their chemical and physical description and is appropriate for the use as stated on the respective technical data sheet when used in compliance with Berry Plastics written instructions. Since many installation factors are beyond the control of Berry Plastics, the user is obligated to determine the suitability of the products for the intended use and assume all risks and liabilities in connection herewith. Berry Plastics liability is stated in the standard terms and conditions of sale. Berry Plastics makes no other warranty either expressed or implied. All information contained in the respective technical data sheet(s) should be used as a guide and is subject to change without notice. This document supersedes all previous revisions, see revision date.

Local distributor / representative

For contact details of local distributor / representative
Please visit www.sealforlife.com

Seal For Life Industries LLC
Houston, TX, USA
Tel: +1 713 676 0085
US Toll Free: +1 888 676 7202
Fax: +1 713 676 0086
houston@sealforlife.com

Seal For Life Industries
Tijuana, Mexico
Tel USA: +1 858 633 9797
Fax US: +1 858 633 9740
Tel Mexico: +52 664 647 4397
Fax Mexico: +52 664 607 9105
mexico@sealforlife.com

Seal For Life Industries BV
Stadskanaal, the Netherlands
Tel: +31 599 696 170
Fax: +31 599 696 177
info@sealforlife.com

Seal For Life Industries BVBA
Westerlo, Belgium
Tel: +32 14 722 500
Fax: +32 14 722 570
belgium@sealforlife.com

Seal For Life Private Ltd.
Baroda, India
Tel: +91 2667 264 721
Fax: +91 2667 264 724
india@sealforlife.com